

## **INSTRUCTIONS FOR USE - CUTLERY**

Dear Customer,

It is important to follow the directions for use because Lagostina's guarantee hinges upon them.

By following these instructions, you will also obtain the best performance from your product. Please keep these directions for use and maintenance for reference. The statements in this document do not prejudice your statutory rights.

### **WARNING**

Do not leave cutlery in contact with food particles which could stain or damage it. Rinse and dry it thoroughly each time after use. Use only soft cloths to clean it – we advise against the use of steel wool and abrasive detergents. Lagostina cutlery can be cleaned in dishwasher. To prevent stains forming, the drying cycle must immediately follow the washing cycle. Should stains form however, remove them simply by using a damp cloth. The products can be only used for what they have been expressly planned. The manufacturer is not responsible for damages caused by improper use.